

BUSHING

8-97364-174-0/8-97220-065-0

ISUZU D-MAX 2WD



8-94223-366-1

ISUZU TFR,KBZ



8-94226-557-2

ISUZU KBZ



8-97364-173-0/8-97220-043-0

ISUZU D-MAX 2WD



8-94408-840-2

ISUZU TFR-TFR (4x4)



8-94118-588-1

ISUZU



9-51151-023-0

ISUZU KBD-S.250/74



8-94171-274-1

ISUZU TFR



5-51351-028-0

ISUZU S.250/79



8-94130-354-0

ISUZU NPR



8-94223-168-0

ISUZU KBZ



8-94113-314-2

ISUZU NKR 85 HP



8-94113-323-2

ISUZU NPR 110 HP.BU-FE. 444



8-94234-319-0

ISUZU KBZ-TFR-RN.25



9-51351-029-0/1

ISUZU S.250/74-NPR



8-94118-589-0

ISUZU NPR 120 HP



8-97081-586-0

ISUZU NPR



5-51151-005-0

ISUZU S.250/76(005)



8-97074-826-0

ISUZU



8-97184-699-1

ISUZU NPR 120HP



8-94408-841-1

ISUZU TFR 4WD



8-97220-077-0

ISUZU D-MAX 4WD



8-97301-506-0

ISUZU D-MAX 4WD



8-97364-177-0
ISUZU



8-97364-176-0
ISUZU D-MAX 4x4



5-51225-002-0
ISUZU TROOPER 83'



8-94408-842-0
ISUZU TFR 4WD



CENTER BEARING

8-94202-520-0
ISUZU KBD25mm



8-97940-059-1
ISUZU TFR



8-94204-520-0
ISUZU KB20



8-94204-521-0/8-94202-521-0
ISUZU KBZ 25mm



8-94328-800-0
ISUZU TFR 30mm



8-94328-799-0
ISUZU TFR(4x4)30mm



9-37516-030-0
ISUZU KS.21-S.250 30mm



5-37516-005-0
ISUZU KS.22-NPR 120 HP 40mm.



5-37516-006-1
ISUZU S.250/79 32mm



9-37510-031-0
ISUZU SBR-FTR 45mm



9-37516-031-0
ISUZU S.68 45mm



9-37516-006-0
ISUZU JCM 45mm



9-37516-008-0
ISUZU BUS 200 HP.



9-37516-045-1
ISUZU BUS 260 HP.(6310) 50mm.



1-37516-043-0
ISUZU FXZ-JCZ



1-37516-045-0
ISUZU FXZ-JCZ



1-37516044-0
ISUZU FXZ-JCZ



1-37510-093-0
ISUZU ROCKY



1-37510-094-0
ISUZU ROCKY



1-37510-095-0

ISUZU ROCKY



1-37510-092-0

ISUZU ROCKY



8-97942-877-0

ISUZU D-MAX 4x4 M/T



8-97942-878-0

ISUZU D-MAX 4x4 A/T



8-94328-799-0SA

ISUZU D-MAX 3.5



8-94222-970-0

ISUZU LUV 1600/2000



1-37510-105-0/1-37516-059-0

ISUZU JCR,SBR,FTR,FSR



**ENGINE
MOUNTING**

9-53215-058-0/179-0

ISUZU TX



8-97146-823-0

ISUZU NQR 125HP.(LH)



8-97146-820-0

ISUZU NQR 125HP.(RH)



5-53215-058-0(2 Screw)

ISUZU S.68



9-53225-116-0

ISUZU JUMBO



9-53225-116-2

ISUZU JUMBO



1-53215-088-0

ISUZU JUMBO 200 HP.



1-53215-048-0/1

ISUZU JCM



1-53215-141-0S

ISUZU ROCKY 175 HP.



1-53215-183-0 (195 HP.)

1-53215-176-0
ISUZU ROCKY 195 HP.



1-53215-135-0

ISUZU ROCKY 210 HP.



1-53215-183-0(240HP.)

ISUZU ROCKY 240 HP.



1-53215-183-0(195HP.)

ISUZU DEGA 195 HP.



1-53215-316-1

ISUZU DEGA 270 HP.



1-53215-141-0/105-0

ISUZU ROCKY 175 HP.



8-97367-272-0/8-97234-976-2
ISUZU D-MAX(RH)



8-97367-273-0/8-97234-977-2
ISUZU D-MAX(LH)



8-97120-497-1/8-97940-319-0
ISUZU NQR130 RH



8-97120-498-1/8-97940-320-0
ISUZU NQR130 LH



8-97079-219-1
ISUZU NPR 120HP. (RH)



8-97079-220-1
ISUZU NPR 120HP. (LH)



5-53215-003-0
ISUZU KB.20 (LH)



5-53215-002-0
ISUZU KB.20 (RH)



8-94225-548-2
ISUZU KBZ 2200 (RH)



8-94225-549-2
ISUZU KBZ 2200 (LH)



8-94104-614-0
ISUZU KBZ(RH)



8-94104-613-0/8-94412-506-0
ISUZU KBZ(LH)



8-94482-408-0/8-94334-159-0
ISUZU TFR 2500 (LH)



8-94482-407-0/8-94334-158-0
ISUZU TFR 2500 (RH)



8-94482-406-0
ISUZU TFR(4x4) (LH)



8-94482-405-0
ISUZU TFR (4x4) (RH)



8-97910-966-0
ISUZU TFR 2800 (RH)



8-97910-967-0
ISUZU TFR 2800 (LH)



9-53215-611-2
ISUZU KS.21 (RH)



9-53215-612-2
ISUZU KS.21 (LH)



9-53215-031-0
ISUZU KS.22 (LH)



9-53215-032-0
ISUZU KS.22 (RH)



9-53215-602-0
ISUZU S.250 - KBD



8-97106-759-0
ISUZU NHR - NKR 110 HP.(LH)



8-97106-758-0

ISUZU NHR - NKR 110 HP. (RH)



8-94172-019-1

ISUZU NPR (LH)



8-94172-018-1

ISUZU NPR (RH)



8-94368-599-1

ISUZU NPR LH.



8-94368-598-1

ISUZU NPR RH.



8-97080-621-0

ISUZU NKR LH.



8-97080-620-0

ISUZU NKR RH.



8-94223-504-4

ISUZU GEMINI LH.



8-94223-674-3

ISUZU GEMINI RH.



8-94365-485-3

ISUZU NPR71'98-99 LH.



8-94365-484-3

ISUZU NPR71'98-99 RH.



5-53215-023-1

ISUZU S.250



5-93225-269-0

ISUZU KBD



8-94135-985-1 / 8-94229-300-2

ISUZU KBZ



8-94434-208-1

ISUZU TFR



8-94472-973-0

ISUZU TFR (4x4)



8-97911-266-0

ISUZU TFR 2800



9-53225-607-0

ISUZU KS.21-22



5-53225-010-0

ISUZU S.250



8-94111-903-0

ISUZU NKR-NPR



8-97367-632-0 / 8-97247-681-1

ISUZU D-MAX



1-53325-033-2

ISUZU JCM



1-53225-192-0

ISUZU ROCKY 175 HP.



1-53225-312-0

ISUZU ROCKY FVZ 195 HP



1-53225-123-0

ISUZU ROCKY 210 HP. JUMBO (LH)



1-53225-119-0

ISUZU ROCKY 210 HP. JUMBO (RH)



1-53225-246-1

ISUZU ROCKY240HP.(LH)



1-53225-245-1

ISUZU ROCKY240HP.(RH)



1-53225-316-0

ISUZU DEGA195-270HP.



9-53225-216-0

ISUZU S.68



1-53215-172-0

ISUZU



5-53215-003-2

ISUZU



1-53225-051-0

ISUZU



8-94225-963-2

ISUZU TROOPER



8-94225-964-2

ISUZU TROOPER



1-53225-390-0

ISUZU



1-53225-391-0

ISUZU



1-53225-268-0

ISUZU



8-97092-068-0/ 8-97126-758-0

ISUZU NHR



8-97092-069-0/ 8-97126-759-0

ISUZU NHR



8-98051-331-0

ISUZU



8-98051-332-0

ISUZU



8-97201-669-0

ISUZU



8-97201-671-0

ISUZU



8-98073-064-0

ISUZU



CABIN MOUNTING & CABIN BUSHING

8-97095-148-0

ISUZU NPR 120 HP



1-54359-142-0

ISUZU JCM 47.5mm. x 22.5mm.



ISUZU FXZ 47.5mm. x 23.5mm.



1-53450-635-3

ISUZU ROCKY 210-240 HP.



1-53459-836-2

ISUZU DEGA 195 HP.
95mm. x 23.2mm.



1-53458-299-0

ISUZU ROCKY CXZ 420 HP
90mm. x 28.5mm.



1-53458-293-1

ISUZU ROCKY CXZ 360 HP
60.5mm. x 15mm.



1-53458-681-0

ISUZU DEGA 270 HP
95.5mm. x 23.2mm.



8-97934-411-0

ISUZU KS,NPR




8-97935-490-1

ISUZU JCM



8-97916-019-0

ISUZU ROCKY 210-240HP.



1-53458-285-0

ISUZU DEGA195-270HP.



8-97136-571-0/8-97095-149-3,0

ISUZU NPR120



8-94235-156-0

ISUZU TFR



8-94157-885

ISUZU TFR



8-94325-155-1

ISUZU TFR



8-94325-160-0/1

ISUZU TFR



8-94325-155-1(2 Pcs./SET)

ISUZU TFR



8-94325-155-1/8-94325-160-0

ISUZU TFR(10Pcs./SET)



8-94380-614-0

ISUZU NPR 110 HP



8-97301-825-2

ISUZU D-MAX



8-97367-288-0/8-97256-676-0

ISUZU D-MAX



8-97301-839-0

ISUZU D-MAX



8-97256-674-1/8-97367-285-0

ISUZU D-MAX



8-97256-677-1/8-97367-289-0

ISUZU D-MAX



8-97256-674-1/8-97367-285-0

8-97256-677-1/8-97367-289-0

ISUZU D-MAX



8-94320-727-1

ISUZU TFR



**AIR
HOSE**

8-94223-151-0

ISUZU KBD



8-94223-157-0

ISUZU KBZ



8-94459-459-1

ISUZU TFR



**STABILIZER
SHAFT
RUBBER**

8-97235-784-0

ISUZU D-MAX 4WD



8-97247-083-0

ISUZU D-MAX



**STABILIZER
LINK**

8-94408-842-2

ISUZU KBD



8-94223-156-0

ISUZU KBZ, TFR



8-94408-853-0

ISUZU TFR 4x4



8-94478-868-0A

ISUZU



SPRING BUMPER

5-53365-012-0

ISUZU KS.22



9-53365-012-0

ISUZU S.250



8-94150-265-1

ISUZU NKR-NPR



9-51172-015-0

ISUZU S.6



9-51772-081-0

ISUZU S.10



9-51172-056-0

ISUZU BUS 200 HP.



1-51172-034-0

ISUZU JCM



1-51172-076-0

ISUZU ROCKY 175-210 HP.



1-51172-074-0

ISUZU ROCKY 240 HP.



8-94223-166-2

ISUZU KBZ



8-94223-165-2

ISUZU KBZ



8-94459-452-1

ISUZU TFR



5-53366-603-0

ISUZU KS.21



9-51391-005-0

ISUZU S.250/74



9-51391-005-0

ISUZU S.250/76



8-94118-510-7

ISUZU NKR-NPR



9-53366-021-0

ISUZU S.68



1-53366-094-0

ISUZU ROCKY 175 HP.



1-53366-093-0

ISUZU JCM,FXZ-ROCKY



8-94226-970-0

ISUZU BUDDY



9-51517-612-1

ISUZU KBD



8-94223-148-2

ISUZU KBZ



8-94433-673-0

ISUZU TFR



1-53366-025-0

ISUZU FXZ-ROCKY



1-53366-026-0

ISUZU FXZ-ROCKY



9-51217-613-2

ISUZU KBD



8-94223-149-1

ISUZU KBZ



8-94259-086-0

ISUZU TFR



8-94234-897-3

ISUZU TFR(4WD)



5-53366-001-0

ISUZU NPR-.250



5-53366-007-0

ISUZU S.250 (2 SCREW)



5-53366-008-0

ISUZU S.250(1 SCREW)



5-53366-007-0(HT)

ISUZU S.250



5-51174-001-0

ISUZU KS.21



8-94433-673-1

ISUZU TFR (SCREW M8)



8-94119-958-1

ISUZU NPR



8-94237-396-0

ISUZU KBZ



**STRUT
BAR
BUSH**


5-51631-699-1

ISUZU KBD



8-94223-699-0

ISUZU KBZ



8-94433-672-0

ISUZU TFR




5-51631-699-1

ISUZU KBD (SET)



8-94223-699-0

ISUZU KBZ (SET)



8-94433-672-0

ISUZU TFR (SET)



DRIVE SHAFT BOOT

8-97138-981-0

ISUZU TROOPER OUTER



8-94312-678-0

ISUZU TFR-OUTER



8-97138-980-0

ISUZU TROOPER INNER



STEERING BOOT

8-97085-356-0

ISUZU TFR



8-97304-852-0

ISUZU D-MAX 2WD



EXHAUST PIPE SUPPORT

8-97080-694-0

ISUZU D-MAX



COUPLING ASSY FLEXIBLE

9-44135-607-0

ISUZU



BOOT CLUTCH RELEASE FORK

8-94156-700-0

ISUZU TFR



HYDRAULIC BRAKE & CLUTCH MASTER

8-94158-051-0B

ISUZU ELF,NPR,NKR(3/4)



5-87830-813-0

ISUZU TFR



5-87830-555-0

ISUZU KAD,KAG(7/8)



5-87830-788-0

ISUZU (1)



5-87831-240-0

ISUZU NPR(1)



5-87830-787-0

ISUZU ELF,NKR(1-1/16)



5-87830-825-0

ISUZU TFR,UBS(5/8)



5-87831-081-0

ISUZU(13/16)



5-87831-043-1

ISUZU(3/4)



5-87831-597-0

ISUZU(3/4)



**DISC
BRAKE
SEAL
KIT**

8-94461-250-0

ISUZU FASTER TFR BIG HORN



8-94242-493-0

ISUZU WFR 10,11



8-94136-643-0

ISUZU FASTER KBD2,UBS52



8-94461-250-01

ISUZU LUV'81



C4901

ISUZU D-MAX

